

## Angular offset wire cutters and nuts drivers



The ExpressTray cable management system is designed to adapt quickly and easily to changing specifications and project requirements. All tray is cut to measure on the job site using these top quality, angular offset wire cutters, bent to the correct radius and then installed using the nut driver and the appropriate ExpressTray hardware and supports.

For the best results, always use ExpressTray wire cutters. With blades made of hardened steel alloy, these wire cutters are easy to use and produce a quick, clean cut. Refer to Figure 1 for correct tool positioning and Figure 2 for wire cutting order. Place all ExpressTray bottom-side up before cutting for optimum results.


Cat no.	Description	lb/ea.	Weight		Overall length	
			kg/ea.	in.	cm	
ET-TOOL	Wire cutter	6.00	2.72	26.0	66.0	
ET-DRIVER	10 mm Nut driver	0.22	0.10	6.5	16.5	
ET-SOCKET	10 mm Nut socket	0.07	0.03	2.5	6.4	

—  
01  
Figure 1 correct positioning – Position the blades on the cross wire and cut away from the new end


—  
02  
Figure 2 cutting order – Place tray bottom-side up and cut wires in the order indicated

Wear safety glasses and gloves when cutting tray.

Warning: Wire cutters often leave sharp projections on the cut wire. For optimum safety, ABB strongly recommends that all sharp ends be removed with an electric grinder or file.



01



02